48” EXERCISE TRAMPOLINE MANUAL

USER’S MANUAL

Adult Assembly Required.
Care, and Maintenance materials enclosed.

⚠ WARNING: ADULT ASSEMBLY REQUIRED.

⚠ ADVERTENCIA: LAS TAREAS DE MONTAJE DEBE REALIZARLAS UN ADULTO.

⚠ WARNING

for use by those 6+ years of age and older
weight limit 200 lbs
proper adult assembly required
safe use requires no more than 1 user at a time

AIRZONE TRAMPOLINE SYSTEM
Bravo Sports 12801 Carmenita Road,
Santa Fe Springs, California 90670 · USA
Assembled in China with USA and China components

Read these materials prior to assembling and using this trampoline.

Table of Contents

Liability 1
Essential Information..... 1
Installation Instructions..... 2
Care and Maintenance..... 2
Use Instructions..... 3
Trampoline Safety and Accident Prevention..... 4
Parts List 5
Assembly 6
Warranty 7

Liability

While every attempt is made to embody the highest degree of protection in all equipment,we cannot guarantee freedom from injury. The user assumes all risk of injury due to use.All merchandise is sold on this condition, which no representative of the company can waive or change.

ESSENTIAL INFORMATION

1. Misuse and abuse of this trampoline is dangerous and can cause serious injuries.
2. Trampolines, being rebounding devices, propel the performer to unaccustomed heights and into a variety of body movements.
3. All purchasers or persons assembling and using the trampoline must become familiar with the manufacturer's recommendations for the proper assembly, use, and care of the trampoline. Also, be alert to the user's limitations in the execution of trampoline techniques and progressions. Suggestions for the care and maintenance are included to promote safe, enjoyable use of this product.
4. It is the responsibility of the owner to insure that all users of this trampoline are adequately informed of all warnings and safety instructions.
5. Always check with your doctor before starting any exercise program.
6. This item has small parts, not for children under 6 yrs. old.
7. Adult assembly required. Care should be taken in the unpacking & assembly of the trampoline.

Not for Professional Use.
Weight Limit for Trampoline User is 200 lb.

INSTALLATION INSTRUCTIONS

- **Adequate overhead clearance is essential. A minimum of 10 ft from ground level is recommended. Provide clearance for wires, ceiling fans, and other possible hazards.**
- **Lateral clearance is essential. Place the trampoline away from walls, structures, furniture, and other play areas. Maintain a clear space on all sides of the trampoline. A minimum of 6 ft from frame edge is recommended.**
- **The trampoline is under heavy tension. Three able-bodied adults are required to set it up. Use appropriate clothing and shoes. Failure to follow these instructions may lead to injury or damage to the trampoline.**
- **Place the trampoline on a level surface before use.**
- **Use the trampoline in a well lighted area. Artificial illumination maybe required.**
- **Remove any obstructions from beneath the trampoline.**
- **The owner and supervisors of the trampoline are responsible to make all users aware of practices specified in the use instructions.**

CARE AND MAINTENANCE INSTRUCTIONS

Inspect the trampoline before each use and replace any worn, defective,or missing parts.

The following conditions could represent potential hazards:

1. **Missing, improperly positioned or insecurely attached frame padding.**
2. **Punctures, frays, tears or holes worn in the bed or frame padding.**
3. **Deterioration in the stitching or fabric of the bed or frame padding.**
4. **Ruptured band.**
5. **A bent or broken frame**
6. **A sagging bed.**
7. **Sharp protrusions on the frame or suspension system.**
8. **Loosened or missing legs.**

For extra protection, periodically apply a silicone spray on stretch-bandstraps to prevent deterioration.

USE INSTRUCTIONS

- Do not allow more than one person on the trampoline. Use by more than one person at the same time can result in serious injuries.
- Keep objects away which could interfere with the performer. Maintain a clear area around the trampoline. Do not allow foreign objects or animals on the trampoline.
- Use trampoline only with mature, knowledgeable supervision.
- The trampoline should be assembled in its entirety before each use. The frame cover should be positioned correctly at all times. By doing this you will prolong the life of the bands by shielding it from the elements and at the same time make the trampoline safer.
- Inspect the trampoline before each use. Make sure the frame cover is correctly and securely positioned. Replace any worn, defective, or missing parts.
- The metal frame of the trampoline will conduct electricity. Lights, extension cords, and all such electrical equipment must never be allowed to come in contact with the trampoline.
- Wear comfortable clothing. Remove jewelry, necklaces, and earrings.
- Step on and off the trampoline. It is a dangerous practice to jump from the trampoline to the ground or floor when dismounting, or to jump onto the trampoline when mounting. Do not use the trampoline as a springboard to other objects.
- Stop bounce by flexing knees as feet come in contact with the trampoline bed. Learn this skill before attempting others.
- Avoid bouncing too high. Stay low until bounce control and repeated landing in the center of the trampoline can be accomplished. Control is more important than height.
- While keeping the head erect, focus eyes on the trampoline toward the perimeter. This will help control bounce.
- Avoid bouncing when tired. Keep turns short.
- Do not use the trampoline while under the influence of alcohol or drugs.
- For additional information concerning the trampoline equipment, contact the manufacturer.
- Bounce only when the surface of the bed is dry.
- Read all instructions before using the trampoline. Warnings and instructions for the care,maintenance, and use of this trampoline are included to promote safe, enjoyable use of this equipment.
- Once the circular steel frame is assembled, it may not be taken apart.

Trampoline Safety and Accident Prevention

As in most recreational sport, participants may be injured. This section covers the most common accidents. Responsibilities of the supervisors and jumpers in accident prevention are also outlined.
The following are reasons why accidents happen:

- **Attempting somersaults**. Landing on the head or neck can cause serious injury, paralysis, or death, even when landing in the middle of the bed.
- **More than one person on the trampoline.** Use by more than one person at the same time can result in serious injuries.
- **Incorrect mounting and dismounting.** Carefully step out of and onto the trampoline bed. Do not jump off to the ground. Do not jump from a table, or other object onto the ground. Do not step onto the suspension system.
- **Hitting the frame**. Stay in the center of the trampoline when jumping. Injury may result from hitting the frame when control is lost. Be sure the frame cover is always on. Do not jump into the frame pad.
- **Loss of control**. A jumper who looses control will increase his/her chance of injury. To regain control and stop your jump, bend your knees sharply as you land.
- **Alcohol and drug use.** Because alcohol and drug use impairs the jumper's coordination, loss of control as well as injuries are greatly increased.
- **Foreign objects.** Please make sure there is nothing sharp under and around the trampoline.Hitting objects under the trampoline can cause injury. Jumping with a foreign object can also increase the chances of getting injured. Be sure there is adequate clearance 10 feet above and 10 feet around the trampoline. Be careful of overhead wires, ceiling fans etc.
- **Poor maintenance of the trampoline.** Make sure you inspect the trampoline before every use. Check for punctures on the bed, sharp burrs on the frame, stitching that has gone bad or loose elastic bands. If a replacement part is needed, please call our hotline to order.
- **Storage.** Once the circular frame is assembled, it may not be taken apart. Remove legs & store entire frame when not in use.

ASSEMBLY INSTRUCTIONS

Place all parts from the box in a cleared area and position them on the floor in front of you. Remove all packing materials from your area and place them back into the box. Do not dispose of the packing materials until assembly is completed. Read each step carefully before beginning.

WARNING: 3 adults in good physical condition are required for the following assembly. Wear proper shoes and maintain balance to prevent a fall. Failure to follow all instructions and warnings exactly may result in serious injury.

1. **Keep children away from the trampoline during assembly.**
2. **Keep finger away from the ends of the rails in the hinge area when unfolding the trampoline. The trampoline will snap into the unfold position. Serious injury can occur if fingers are caught between the ends of the RAILS.**
3. **When unfolding the trampoline, the RAILS will try to spring back to the folded position if they are released before they snap into place.**
4. **The Safety Pads must be installed before using the trampoline.**



PART NO. and DESCRIPTION	QTY.
1. Top Rail 1	1
2. Top Rail 2	1
3. Top Rail 3	1
4. Top Rail 4	1
5. Mat	1
6. Safety Pad	1
7. Leg	8
8. Leg Cap	8
9. Bolt	2
10. Wrench	1
11. Washer	2
12. Manual	1

ASSEMBLY

Refer to PARTS LIST for identification of parts.



1 Lay all the parts down and open the bed.



2 Connect two joints shown above.Do not connect the joints with the lip yet. Be careful not to pinch your fingers.

3 With the 2 joints connected, position the 2 half circle sections shown. Note that the top circle is resting on the welded lips of the bottom section.



4 With 2 people applying their weight on the frame and a third person on the other side, slowly open the two half circles. Be careful and keep the joints within the lip space. Please be careful! There is a lot of tension here and severe injury may occur if these instructions are not followed.

5 Continue opening the circle until the joints lock together. Again,there is a lot of tension here and take extra precaution in avoiding any pinch points.



6 Inspect the frame and make sure it is straight and round. You may have to move the sections to do this. Even out all the bands.

7 To provide additional support for the frame, we have included 2 bolts and washers to fasten the joints together. We have also provided a wrench to securely tighten the bolts. Periodically check to make certain they are tight

8 After the frame has locked into place, remove the plastic caps from the threaded sockets and insert the frame cover through the first socket.

10 Congratulations and have fun with your trampoline.



9 Continue this with the other 7 holes and straighten the cover making sure it's evenly covering the suspension system. Screw the 8 legs on.

90 DAY LIMITED WARRANTY

Subject to the following limitations, in addition to any imposed by virtue of applicable law, Bravo Sports warrants this trampoline to be free of defects in material or workmanship for a period of 90 Days from the date of original purchase. This warranty is limited to the repair and/or replacement of defective parts only.

1. This Limited Warranty will apply only if the Trampoline and/or its parts are properly returned to the Customer Service Department listed below and are determined by Customer Service in its sole discretion, to be defective.

2. This Limited Warranty applies only to Bravo Sports trampolines purchased from authorized dealers. Limited Warranty is extended only to the original consumer purchaser and is not transferable.

3. Be sure to retain your original purchase sales receipt for any warranty claim. All warranty claims must be accompanied by the original purchase receipt from the authorized dealer.

4. Before returning any Trampoline and/or parts to Customer Service for warranty inspection, the consumer purchaser must obtain prior authorization from Customer Service. Such authorization can be obtained by calling our customer service representatives at the toll-free numbers listed below or writing to the Customer Service Department at the address listed below. Customer is responsible for all shipping costs.

5. This Limited Warranty does not cover damage or loss from: wind, rain, fire, snow, ice, or other forces of nature; accident; normal wear; improper assembly, disassem bly, or adjustment during set-up or take-down; or any abuse, neglect or misuse of this trampoline and/or its parts. Any alteration to the original product voids the warranty.

6. To the extent allowed by applicable law, any implied warranty of merchant ability or fitness applicable to this Trampoline is limited to the duration of this Limited Warranty. Bravo Sports does not warrant against, and in no event shall Bravo Sports or its authorized agents be liable for, any personal loss, injury, or direct or indirect incidental or consequential damage resulting from the use of this product. Please note that some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This Limited Warranty gives you specific legal rights and you may have other rights which vary from state to state.

7. Upon receipt of authorization from our Customer Service Department, you must submit your warranty claim to the address below, shipped prepaid and accompanied by the original dated purchase receipt. Do not return this product to the place of purchase.For warranty service, or for missing parts, replacement parts or any other problems, call or write to our Customer Service Department below. We will send any replacement parts via U.P.S. Ground.

Bravo Sports 12801 Carmenita Road, Santa Fe Springs, California 90670
Service Hotline: (800) 248-5327